

Use unplanned timber 22mm thickness, tongued and grooved will be fine.

Put together with galvanized nails, please put a piece of roofing felt on the top, it will extend the lifetime of the nest.

Put wood oil on the outside, but not on the inside.

The entry hole should be

D = 30mm for the Blue tit.

D = 35mm for the Great Tit

D = 35mm for European Pied Flycatcher

Fix the nest properly so that it does not fall down when the wind blows hard, but remember not to destroy the tree in the process.

The birds will love if you put the nest facing north, thus avoiding extream heating from the sun.

